

ARIS EDGE BLE Sensors Demo

Application Note

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by RELOC s.r.l. without notice.

Doc: R16P10DTAN00, Rev: 1.0 1 of 14



Outline

Αc	cronyn	ns		4
)	
			quirements	
	2.1		ware Requirements	
	2.2		/are Requirements	
	2.3		o loading	
	2.3.		Synergy S1 programming	
	2.3.	.2	Silicon Labs MGM111 programming	
3.	Desig		rview	
	3.1	Func	tionalities	9
	3.2	Archi	tecture	9
	3.3	Data	sharingsharing	. 10
	3.4	BLE i	interface	. 11
	3.4.	.1	S1 versus BLE communication	. 12
	2 /	2	PLE communication coguence	12



Revisions

REVISION	DATE	DESCRIPTION	STATUS	Author	REVISER
0.1	26/09/2017	Document created.	draft	C. Tagliaferri	
1.0	28/09/2017	Document released	release	C. Tagliaferri	A. Ricci

Disclaimer

All rights strictly reserved. Reproduction or issue to third parties in any form is not permitted without written authorization from RELOC s.r.l.

RELOC s.r.l. Phone +39-0521-1759942

HEADQUARTERS www.reloc.it
Via Borsari, 23/A 43126 – Parma (Italy) info@reloc.it

Doc: R16P10DTAN00, Rev: 1.0 3 of 14



Acronyms

APP Mobile Application

BLE Bluetooth Low Energy

DOF Degrees of Freedom

IMU Inertial Measurement Unit

MCU Micro Controller Unit

S1 Renesas Synergy S1 MCU

Doc: R16P10DTAN00, Rev: 1.0 4 of 14



1. Introduction

The ARIS EDGE "BLE Sensors" project demonstrates sensing and communication capabilities of the ARIS EDGE board.

BLE Sensors demo code periodically reads values from the on-board sensors (i.e. 9-DOF IMU, temperature, humidity and pressure and light sensing devices) and makes them available on the BLE interface. Moreover, the same BLE interface allows for driving (turn on and off) the ARIS EDGE LEDs. ARIS Tools mobile application is provided in order to interact with the ARIS EDGE board through BLE interface.

The project is based on Renesas Synergy SSP 1.3.0 framework and the demo workspace is tested using Renesas e2 studio (version 5.4.0.023).

In the following, the architecture and functionalities of the ARIS EDGE BLE Sensors demo are detailed.

2. System Requirements

2.1 Hardware Requirements

- ARIS EDGE board R1.1
- Mini-USB cable
- J-Link programmer used for the MGM111 firmware loading (sensors demo firmware is preloaded at production so it could not be necessary).
- Android or iOS smartphone with the "ARIS Tools" APP.

2.2 Software Requirements

The project has been developed with:

- Renesas Synergy SSP 1.3.0 framework
- e2studio 5.4.0.023
- BGtool 2.3.3-2346 (for the MGM111)

2.3 Demo loading

In order to execute the ARIS Sensors demo, both Synergy S1 microcontroller and Silicon Labs MGM111 system-on-chip should be programmed.


2.3.1 Synergy S1 programming

Synergy S1 programming could be performed exploiting e2studio IDE and the ARIS EDGE on-board J-Link debugger.


Doc: R16P10DTAN00, Rev: 1.0 5 of 14



Connect the ARIS EDGE board J5 mini-USB to the host PC. Launch e2studio IDE and import the ARIS EDGE Sensors demo Synergy archive project by selecting File \rightarrow Import from IDE menu and Existing Projects into Workspace option in the dialog box; press the Next button.




Browse for the S1 project archive file ($ARIS_EDGE__Demo_BLE_Sensors_v1_3_0.zip$) and press Finish button to confirm the importing procedure.



Doc: R16P10DTAN00, Rev: 1.0 6 of 14



After successful project import, navigate the project tree in Project Explorer and double click on project configuration file, configuration.xml.



Generate Synergy project contents by pressing the Generate Project Content button.

Build the project selecting the $Project \rightarrow Build$ All menu. Build process should finish without errors nor warnings (see the Console tab below).

```
Prin Conflicts Console Console Console Console Properties Problems Search

CDT Build Console [Demo_BLE_Sensors]

'Finished building: Demo_BLE_Sensors__$1.siz'

'I console Co
```

In order to download the demo project into S1 device, open the $Run \rightarrow Debug$ Configurations dialog, select the Demo BLE Sensors configuration and press Debug button to confirm.

The IDE automatically moves to the <code>Debug</code> perspective. Launch the demo code by pressing the <code>Resume</code> button button twice.

Doc: R16P10DTAN00, Rev: 1.0 7 of 14



2.3.2 Silicon Labs MGM111 programming

ARIS Sensors demo requires that " $Demo_BLE_Sensors__MGM.bin$ " binary file is loaded into MGM111 device.

Please refer to "ARIS EDGE User Guide" – section 3.3 for the detailed procedure.

Doc: R16P10DTAN00, Rev: 1.0 8 of 14



3. Design overview

3.1 Functionalities

ARIS EDGE BLE Sensors demo implements functionalities as follows:

- periodically sampling of all the on-board sensors, including
 - BNO055 9-axis absolute orientation sensor
 - o TSL2571 Light-to-Digital Converter
 - BME280 Combined humidity and pressure sensor

with visual warning if the drivers' initialization fails.

- communication with the multiprotocol MGM111 module in order to make data available to external BLE clients and provide access to LEDs control.
- trace the whole system's events using a serial port as debug output.



Figure 1 - Demo sensors high level diagram.

3.2 Architecture

In the sensors demo three threads are present. Each one of them handles a specific functionality:

Sensors Thread: manage the sensors reading the current values from them.
 In this thread a simple auto-diagnostic function has been introduced at boot; the orange

Doc: R16P10DTAN00, Rev: 1.0 9 of 14

LED2 is turned on after the drivers' initialization and then turned off few seconds later after the very first sampling. If LED2 does not execute this sequence one or more sensors are not working correctly.

- BLE Thread: its purpose is to control the communication with the MGM111 external module using a serial port.
- Console Thread: periodically reads the data available of the sensors and output the values on the debug serial console.




Figure 2 - Threads blocks diagram.

As it can be noticed from Figure 2, a synchronization system is present at boot time in order to wait that all the shared components are correctly initialized before their use. This system is based on a simple event-flags ThreadX primitive.

3.3 Data sharing

In a multi-thread system where data must be accessible from different threads, a mutex protection system must be used.

Doc: R16P10DTAN00, Rev: 1.0 10 of 14



In this demo an advanced sharing system has been implemented, the "data queue" module. Its main features are:

- Oppositely to the standard synergy messages system, it is allowed to have different polling frequency to the data from different threads. If a thread is too slow to empty the queue, or even stops to read, when there is no more space in the queue this module simply discards the oldest data.
- No owner concept, everyone can write to (or read from) the module.
- Mutex protection for multi-thread applications.
- Possibility to read always the last data only (no queue).

Note that this module has been specifically designed for this application requirements. For example data loss in case of a slow-reader is acceptable and writers will always be able to add data to the queue (ignoring the queue status).




Figure 3 - Data flow.

3.4 BLE interface

The multiprotocol MGM111 has been programmed with a custom firmware that enables the BLE interface and exposes the services detailed in the following table.

Service UUID	Characteristic	Description
	2A56	LED2
1815 (Automation Service)	2A56	LED3
	2A56	LED5
	AA01	Temperature (float) [°C]
AA00 (custom)	AA02	Humidity (float) [%RH]
	AA03	Pressure (float) [hPa]

Doc: R16P10DTAN00, Rev: 1.0 11 of 14



	AA04	Illuminance (float) [lux]
	AA11	Accelerometer X (float) [mg]
AA10 (custom)	AA12	Accelerometer Y (float) [mg]
	AA13	Accelerometer Z (float) [mg]
	AA21	Gyro X (float) [dps]
AA20 (custom)	AA22	Gyro Y (float) [dps]
	AA23	Gyro Z (float) [dps]
	AA31	Magnetometer X (float) [uT]
AA30 (custom)	AA32	Magnetometer Y (float) [uT]
	AA33	Magnetometer Z (float) [uT]

Apart of the LED service, clients can subscribe to the characteristics so that they will be automatically notified when the values change. This is the mode used from the mobile APP.

3.4.1 S1 versus BLE communication

The protocol between BLE and S1 is made of a predefined fixed-length commands.

The "BLE to S1" commands are used to inform the S1 of some user requests or for acknowledge a previous S1 command. These commands have a 6-char fixed length with a "\r\n" terminator used as alignment control.

BLE to S1		
Command (6 chars)	Description	
"B \r\n"	SW3 pressed event (not used in this demo)	
"L1 0\r\n"	Turn off LED3	
"L1 1\r\n"	Turn on LED3	
"L2 0\r\n"	Turn off LED2	
"L2 1\r\n"	Turn on LED2	
"K \r\n"	Acknowledge to sensor's data	
"C \r\n"	BLE client connected event	
"D \r\n"	BLE client disconnected event	

The "S1 to BLE" commands are instead the commands sent to the BLE module for data values notifications or for LED5 activation. Note that LED5 commands coming from a BLE client are directly handled by the MGM and they are not notified to the S1.

Doc: R16P10DTAN00, Rev: 1.0 12 of 14



S1 to BLE		
Command (8 chars)	Description	
"L50 \n"	Turn off LED5 (not used in this demo)	
"L51 \n"	Turn on LED5 (not used in this demo)	
"T nnnn\n"	New temperature value	
"H nnnn\n"	New humidity value	
"P nnnn\n"	New pressure value	
"I nnnn\n"	New illuminance value	
"AX nnnn\n"	New accelerometer, x axis, value	
"AY nnnn\n"	New accelerometer, y axis, value	
"AZ nnnn\n"	New accelerometer, z axis, value	
"GX nnnn\n"	New gyro, x axis, value	
"GY nnnn\n"	New gyro, y axis, value	
"GZ nnnn\n"	New gyro, z axis, value	
"MX nnnn\n"	New magnetometer, x axis, value	
"MY nnnn\n"	New magnetometer, y axis, value	
"MZ nnnn\n"	New magnetometer, z axis, value	

3.4.2 BLE communication sequence

BLE module has been programmed using BGScript.

The commands sent from S1 microcontroller to the module are alternated with a short sleep period and a trivial acknowledge mechanism has been also used.

At boot time no communication is initialized between S1 and BLE module.

The trigger event is a client connection, communicated from the BLE module to the S1 MCU. After this event the S1 starts to read the last sensors' values from the "data queue" and send them to the BLE, one value at a time. After each value, the MCU waits for an acknowledge response from the BLE and then sleep for a predefined period before sending the next value.

The loop ends when a disconnection event is received from the BLE module only.

Doc: R16P10DTAN00, Rev: 1.0






Figure 4 - BLE finite state machine.

Doc: R16P10DTAN00, Rev: 1.0 14 of 14